



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

01-040-0223-0

Installation Instructions Front Rallye Fender R1150GS

contains:

- 1 x Front Rallye Fender R1150GS
- 1 x Support brace left
- 1 x Support brace right
- 6 x Screw domehead M5x12
- 4 x Nylock nut M5
- 4 x Washer M5 large
- 6 x Washer M5 small



Preparation:

Remove first the front wheel of your R1150GS. Information regarding front wheel removal can be found in the owner`s manual. Remove then the speedometer cable guide off the front fender. This will later be used with the Rallye front fender but the cable does not need to be removed completely off the bike. Now remove the original front fender. It is attached left and right with one screw each side as well as additional two crews from below on the fork bridge.

Installation:

Attach first the Rallye fender with the two original screws from below on the fork bridge. Now set the front wheel again between the forks and attach the brake calipers. Information regarding this can be found in the owner`s manual.

Attach next the left and right support braces on the inside of the Rallye fender each side with two dome head M5x12, two washers M5 large (under screw head), two washers M5 small (under the nylock nuts) and two nylock nuts M5, Attach then both support braces on the forks with one M5x12 screw dome head and washer M5 each side.

Reinstall the front wheel according to BMW instructions and to BMW torques specs.

Make sure to control tightness of all screws in regular interwals.

