



# TOURATECH

TOURING RALLYE RACING TECHNOLOGY

March 2002

## 01-040-0235-0

## Low Fender F650GS/ Dakar

### Parts included:

- 1x Low mudguard
- 4x 25mm Spacer
- 4x 25mm-longer Allen screws
- 1x flat spacer (for 2002 fork brace)

## Mounting F650 GS :

(using original screws and spacers)

It is not necessary to remove the front wheel. For F650GS-A, the mudguard fits directly under the fork brace, with original screws and spacers. Undo the nut from the left hand rear screw, and remove the brake pipe holder. Next undo the four screws and remove the fork brace. Fit the mudguard onto the original spacers using the original screws.

For 2001: Place the fork brace directly on top of the mudguard, the flat spacer is not necessary.

For 2002 and newer: Place the flat plate spacer on top of the mudguard, then the fork brace on top of the flat plate spacer.

Tighten to 21Nm. Refit the brake pipe holder and nut.



## Mounting F650 Dakar:

The mudguard fits in similar fashion, but it must be raised to clear the 21" wheel. Use the longer screws and spacers for 21" wheel.

For 2001: Place the fork brace directly on top of the mudguard, the flat spacer is not necessary. Replace the original short spacers and bolts with the longer set provided.

For 2002 and newer: Place the flat plate spacer on top of the mudguard, then the fork brace on top of the flat plate spacer. Replace the original short spacers and bolts with the longer set provided.

Tighten to 21Nm. Refit the brake pipe holder and nut.