



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-040-0330-0

Installation Instructions Head Light Guard R1150GS

Contains:

- 1 x Polycarbonate Head Light Guard R1150GS
- 2 x Spacer Aluminium 60mm
- 2 x Screw dome head M5x70
- 2 x Washer large M5



Installation - Head Light Guard R1150GS:

Remove the protective cover on the Touratech head light cover,
Remove then the original screws that hold the head light retaining bracket.
Be careful not to drop the head light after removing screws!
Attach the head light cover both sides with one M5x70 screw and a 60mm spacer,
Place the washers between the screw head and the head light cover.



NOTE:

This head light cover does not have German TUV approval and is therefore not street legal in Germany.

These instructions are at our current level of knowledge. Legal requirements do not exist. Technical issues subject to change.