



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

01-040-0601-0
01-040-0603-0
01-040-0604-0

Installation Instruction Crossbar

Contains:

- 1 x Handlebar crossbar
- 4 x C-clamp
- 2 x Screw M6x30
- 2 x Screw M6x25
- 4 x Nylock nut M6
- 8 x Washer M6



General Installation Suggestion:

Preassemble the bar by loosely installing the clamps on the bar using M6x30 screws (1), nylock nut M6 and washers M6 under screw head as well as nut.

Set bar on the handlebars and attach other side of the clamp with M6x25 screws (2), nuts M6 and washers M6.

Adjust bar and tighten all screws evenly.

