



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

October 2002

01-040-0654-0

Mount Adapter R1100S

Parts included:

- 1 x mount adapter BMW R1100S
- 4 x allen screw M6 x 40 LiKo
- 4 x washer M6
- 4 x self-locking nut M6



Assembly:



Put the mount adapter on the upper fork bridge, with the longer attachment tabs to the rear. Pass the two plates under the upper fork bridge one at a time, and hold while passing the bolts through the mount adapter tab and the plate. Use a washer and M6 locking nut on each bolt. The adapter is above the fork bridge, the two plates are below the fork bridge.

Align the mount adapter before finally tightening the screws. Any of our GPS mounts can be installed on the mount adapter with no problems