



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

01-040-0660-0

Installation Instruction:
Universal GPS Adapter

Contains:

1 x Universal GPS mount adapter
2 x Spacer short
2 x Spacer long
2 x Screw hex internal M6x40
2 x Screw hex internal M6x50
1 x Screw short hex
1 x Lock washer
2 x Washer M6

Note:

This adapter is a universal design. Some motorcycles may require hardware that are not included in the kit.



Installation:

Loosen the stock brake or clutch lever clamp screws.

Set two screws with washers through the elongated holes on the adaptor lower part and then slide spacers on the screws behind the adaptor.

Choose appropriate spacer and screw set so that the thread depth of the screws tightened is equal to stock screws. Tighten bolts to 12Nm

Install now the Touratech GPS mount on the top adapter bar.

Attach then the top bar on the lower adaptor part using supplied short hex screw and lock washer (see arrow) and tighten it with the supplied tool.