

Touratech-USA

040-0661 BMW R1150RS GPS mounting adapter

Bill of materials:

1 x mounting adapter R1100/1150RS
4 x screw lens head M5x45
4 x nut self-locking M5
4 x u-disk largely M5
4 x u-disk M5

Mounting:

Mounting of adapters for the BMWs R1100/1150RS and R1100S is put on with the handle to the rear on the fork bridge. The screw connection takes place with the two enclosed shims, the four screws lens head M5x45 with small u-disks M5 above, large u-disks M5 down as well as the four nuts self-locking M5 under the fork bridge. The shims inside set under the fork bridge the longer arm of the shim points forward in each case.

Onto the cultivation adapter you can install any of the Touratech aluminum GPS mounts now. Information for this takes you please from the respective guidance. The example shows the mount of the Street Pilot III.