

09-040-0664-1  
09-040-0665-1

## Installation Instructions GPS Mount Adapter R1200GS

### Contains:

- 4 x Special Screws
- 2 x Triangular bar holding bracket
- 1 x 4 inch round bar
- 2 x Screw dome head M6x12
- 4 x Screw hex M5x10
- 2 x Washer M6
- 4 x Washer M5
- Cable ties

### Installation:

Loosen the handlebar clamp screws and replace them with the supplied Touratech special screws. It is recommended to screw the bolts in all the way by hand (with upper clamp portion removed). Also recommended to use anti-seize on threads. Anti-seize is a messy gray thread lubricant, you will know if it is there. Sometimes the BMW shop has already used anti-seize.

Tighten the handlebar clamps and install the triangular bar holding brackets with the M5x10 hex screws and washers M5.

You can choose to install the brackets so that the bar will either be front or back.

Install the bar with the M6x12 screws and washers to the triangular bar brackets. Zip ties can be used if the throttle cable rubs against the right bracket. Now you can install Touratech GPS mount on the bar.

