



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

01-040-1005-0

Installation Instruction: Carbon Fibre Front Fender R1150 GS/ Adv

Contains:

1 x Carbon fibre Front Fender R1150GS / Adventure

Installation:



1. Removal of front wheel and stock front fender:

Please remove first the front wheel based on BMW instructions.

Remove then the speedo cable guides of the fender. Now remove the original front fender. It is attached right and left close to the brake calipers as well as under the fork bridge.

2. Installation of Carbon Fibre Fender:

Carbon Fibre Front Fender can be installed now. Attach the fender with the two original screws under the fork bridge.

3. Reinstallation of front wheel:

Set front wheel again between the forks and attach both brake calipers. Install then the front wheel also following BMW instructions.

Check the tightness of all fasteners in regular intervals!



Note regarding speedo cable:

Approximately 10,5mm hole needs to be drilled on the left side of the carbon fibre fender where the speedo cable guide can be attached just as on the original fender!