



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-040-157X-1

Installation Instructions Large Spoilers for Hand Guards

Contains:

- 1 x Spoilers for hand protectors (pair)
- 4 x Screw dome head Phillips M4x12
- 4 x Nylock nut M4
- 4 x Washer large M4
- 4 x Washer M4
- 4 x Spacers 7,4,4



Installation:

The spoilers are attached on the hand guards as shown on photos. Insert the tab in the middle of the lower edge of the spoiler into the hole on the hand guard.

Set two screws dome head Phillips M4x12 per spoiler with washer M4 under the screw head from the front or outside. Set then the spacers from the back or inside and large washer M4 and tighten with nylock nuts.

