



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-040-1701-1

Installation Instructions Spoilers for original hand guards R1150 GS/Adventure

contains:

- 2 x Spoiler
- 4 x Screw dome head M4x12
- 4 x Washer M4
- 4 x Nylock nut M4

Installation:

Remove original hand guards and set the spoilers on the inside of them. Mark bore holes on the hand guards with the help of the spoilers and drill 5mm holes. Photo 1.

Attach the spoilers with supplied M4x12 dome head screws, washers and nylock nuts on the hand guards. Photo 2.

Reinstall the hand guards on the handlebars.

