



01-040-2001-0

Additional Foglight
R1150GS/ Adventure

Parts included:

- 1 x fog headlight including cables and connection port
- 1 x bracket
- 2 x washer M5 small
- 2 x washer M5 large
- 2 x caphead screw M5x20
- 2 x caphead screw M6x12
- 2 x caphead screw M6x16
- 4 x washer M6 small

Perform all electrical work with ignition switched off and the battery disconnected!!

Assembly of the headlight:



First you must bolt the fog headlight unit to the provided bracket with two caphead M6x12 screws and washers. Now screw the light and bracket onto the front support at the right on the original fender attachments with two caphead M5x20 screws and washers. Put two small M5 washers between bracket and fender. Screw connections together loosely, the headlight adjustment is done with these later. (Photo 1)



Electrical connection:

Remove seat and tank. Install the relay with the cable straps to the frame. (Photo 2) Pull the brown cable to the negative post of the battery and shorten it accordingly. Do not attach the provided round eye adapter to the battery yet. Bring the blue and red cable to the headlight and the toggle switch to the handlebar. Bring the yellow cable to the connection plugs on the frame. (Photo 3) Shorten the cable to suitable length and crimp it with the provided cable connector to the blue/gray cable coming from the smaller black box. The cable must be in the plug completely to connect.



01-040-2001-0

Additional Foglight
R1150GS/ Adventure



Electrical connection: Bring the switch to the handlebar and install it at the left side directly beside the clutch perch with the provided clamp, two caphead screws M4x10 and two nuts M4. Adjust the switch so that it can be flipped vertically. (Photo 4)



Shorten the blue and red cable to correct lengths and pull them through the two paths planned for them to the lower part of the foglight rear cover. Attach the provided flat pins to the cables. Plug the blue cable into the foglight on the outside right. This is the ground wire. Attach the red cable directly at the light. (Photo 5) Bring the cover over the foglight. Attach the battery and the ground wire of the foglight.

With parking light on the foglight should be able to be switched on now. Align the foglight and tighten all bolts. Screw the headlights onto the screen with the LiKo M6x10. Fix the lines with cable straps.

Pay attention that the cables cannot be severed or squeezed and are routed so that parts do not overheat. Secure all cables with cable straps, install tank cover and seat. The auxiliary headlight can be aligned by easily shifting it in the slotted hole in the mount.