

09-040-5400-1

Installation Instructions Radiator Guard Triumph Tiger 955i

Contains:

- 1 x Radiator Guard Triumph Tiger 955i anodized
- 2 x Screw hex dome head M6x45
- 2 x Washer large M6
- 2 x Spacer

TOUR ATECH

NOTE: DESIGN MAY VARY FROM PICTURED MODEL !

Installation:

Radiator guard is attached at four postions. On the top the origial screws and washers are used for Touratech radiator guard. Set washers directly under the screw heads on the radiator guard. Attach the guard below with the spacers, screws M6x45 and large washers M6.

The two spacers are positioned behind the radiator guard to adjust the distance to the threads.



These instructions are at our current level of knowledge. Legal requirements do not exist. Technical issues subject to change.