


**Anleitung: Handschutzbügel GD  
BMW R1150GS / ADV  
für Stahllenker**

Lieferumfang:  
1x Handprotector GD  
1x Anbausatz

**Achtung! Wichtige Hinweise**  
**Nach der Montage muss die**  
**Freigängigkeit von Kupplungs- und**  
**Bremsgriff kontrolliert werden, ebenso**  
**beim Gasgriff.**

**Montage**

Demontieren Sie zuerst die Originalen  
Protektoren, wenn vorhanden.

Befestigen Sie nun den Protektor am  
Lenkerende. Nehmen Sie dazu das  
eloxierte Lenkerendstück und schrauben  
ihn mit der M8x25 und dem Unterlegteller  
an, A.

Schrauben noch nicht festziehen.

Platzieren Sie die Lenkerklemme wie in  
Bild B zu sehen. Dazu brauchen Sie die  
Schrauben M6x40, 2x, die U-Scheiben  
und die Mutter SeSi M6. Ebenso die  
beiden Distanzen.

Schrauben noch nicht anziehen.

Schrauben Sie jetzt den Protektor, mit der  
Schrauben M6x20 und der U-Scheibe M6  
groß, an der Klemme bzw. an der Distanz  
fest, C.

Schraube noch nicht anziehen.

Bringen Sie nun den Protektor in die für  
Sie richtige Position und ziehen die  
Schrauben fest.

Darauf achten, das die Freigängigkeit von  
Brems-, Kupplungs- und Gasgriff durch  
den Protektor nicht beeinträchtigt ist.

**Installation Instruction: Hand  
Protector GD R1150GS/ADV OEM  
Steel Handlebar**

Contents:  
1 x Hand protectors left and right  
1 x Insallation material

**Attention: important tips, explanations**  
**Carefully check that both levers and**  
**throttle operate freely after the**  
**installation before your first ride!**

**Assembly**

Remove first the original handguards if  
installed.

Install left and right protectors on  
handlebar ends using the supplied  
anodized bar end using screws M8x25  
and spacer/washer, A.

Do not tighten screws yet.

Set the handlebar clamp as shown in  
photo B. Use two screws M6x40,  
washers and nylock nuts M6 with short  
and long spacers.

Do not tighten screws yet.

Install the handguard inner end with  
screw M6x20, washer M6 large on the  
long spacer, C.

Do not tighten screws yet.

Adjust handguards and tighten scews, D.

Check that both levers and throttle  
operate freely after the installation before  
your first ride!

