



09-041-0205-1

Installation Instructions Radiator Guard Suzuki V-Strom DI1000

Contains:

1 x Radiator Guard, 1 x Hex Screw M5x25,
2 x Hex Screw M5 x 16, 2 x Nylock Nut M5,
5 x Washer, 1 x Sheet Metal Nut M5, 1 x Spacer 16x6,2x12



1. Installation:

Push the radiator guard from front over the radiator. Set the upper tabs between the upper radiator supports.

Loosely attach the tabs and the radiator supports thru original screw bores with M5x16 screws and Nylock nuts M5. Use washers under the screw heads as well as the nuts. Photo 1



2.

Loosen the radiator supports on front cylinder head (M6 screw).

Set the lower tab between radiator and cylinder head and loosely tighten the original screw. Photo 2



3.

Set the M5 metal nut above the original tab (thread up). Photo 3.

Set the spacer between the tab and the radiator guard and attach with M5x25 screw and washer finger tight.

Tighten all screws to max. 15Nm torque.