



# TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-041-0601-1  
09-041-0603-1  
09-041-0604-1

**Installation Instructions  
Rallye Foot Pegs**

**Transalp, Africa Twin, Varadero, XR650R, V-Strom DL1000**

Contains:  
2 x Foot Peg  
2 x Split pin

**Installation:** Remove the split pin on the under side of the foot peg holding bolt and pull then the bolt out.  
Remove the foot peg and the original spring. Set the spring in the Touratech Rallye foot peg.

## Transalp



Set the new foot peg in the foot peg mount. Make sure that the spring pushes the peg downwards.

Reinsert the bolt thru the peg and peg mount and secure with new split pin.  
Do not forget washers if they were installed with original peg..

## Right

## Left



## Varadero



## Africa Twin