Dezember 2003

01-041-0703-1,01-041-0705-1 01-041-0707-1,01-041-0711-1 Installation Instructions
Folding Shift Lever A-Twin, Transalp, Varadero, V-Strom 1000

Contains:

1 x Folding shift lever

1 x Screw hex M6 x 25

1 x Washer

Loosen the clamp screw on the original shift lever and remove it from the lever. Now you can remove the stock shif lever. It may be difficult to pull out so you can carefully pry the clamp gap open with flat head screw driver.

(For Varadero: remove collar; it will no longer be used)

Remove the screw of the Touratech shifter and push the lever in wanted position on the gear shaft.

Test the position with your riding boots, insert the screw and tighten to max. 10Nm torque.

Check the tightness of the screw after 50 miles and in regular intervals after that.