



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

November 2003

09-044-0230-1

Installation Instructions Rear Fender Tabs Cover R 1200 GS

Package contains:

- 1 x Rear Fender Tabs Cover
- 2 x Dome head hex screw M6x14
- 1 x Dome head hex screw M6x08
- 2 x Washer M6

Remove the rear plastic fender and the brake caliper. Remove the spacer sleeve and attach the Touratech cover as shown on the photo with the M6x14 screws and washers M6.

Reinstall the brake caliper and tighten the bolts to 24Nm and use lock tite type compound on the bolts.

The screw M6x08 is used to cover the extra hole left that is pointed out with the arrow on the photo.

