

April 2005

## Anleitung LED Blinkersatz flexibel R1200 GS

### Lieferumfang:

4 x LED-Blinker  
2 x Unterlage V2A vorne  
2 x Distanz vorne  
2 x Unterlage V2A hinten  
2 x Distanz hinten  
4 x Linsenkopfschraube M6x30  
4 x U-Scheibe M6

### Demontage:

Entfernen Sie zunächst die Blinkergläser der original Blinker. Nehmen Sie die Blinkereinsätze heraus und ziehen Sie die Kabelschuhe von den Anschlüssen herunter.

Lösen Sie jetzt die Befestigungsschrauben der Blinker, entfernen Sie die Blinker und ziehen Sie dabei die Kable aus den Blinkern heraus.

### Montage der LED-Blinker:

Jetzt die V2A Unterlage (kürzere gehören nach vorne) am Blinker mit der M10 Mutter und U-Scheibe verschrauben. Anschließend Kabel durch die Distanz (kürzere gehören nach vorne) ziehen und anschließen.

Anschlußstecker mit Schrumpfschlauch isolieren

Jetzt Blinker und Distanz mit der M6x30 Linsenkopfschraube und je einer U-Scheibe anschrauben, auf Funktion prüfen.

## Installation Instructions LED Blinkers Flexible R1200GS

### Contains:

4 x LED Blinker  
2 x Underlay SS front (vorne)  
2 x Spacer front (vorne)  
2 x Underlay SS rear (hinten)  
2 x Spacer rear (hinten)  
4 x Screw dome head M6x30  
4 x Washer M6

Remove first the original blinker glasses by unscrewing one phillips screw on the back. Remove the blinker reflectors, make note which BMW wire is ground- and which positive+ (most bikes should have brown ground - and blue/red 12V+ which should be touching the middle of the bulb) and disconnect the cables off the back of the reflector. Loosen the blinker stalk attachment screw and remove the stock blinkers by pulling the wires thru.

### Installation:

Take the M10 nut and washer off the Touratech blinker stalk. As shown on photos, put the stainless steel underlay V2A (smaller ones go front) on the blinker stalks and tighten with the stalk M10 nut and washer. Put the black plastic spacer on the stalk M10 nut.

Connect the wires coming out of the Touratech blinker with your original BMW wires and isolate the connectors (shrinkable tubing enclosed). Attach the Yellow wire from the blinker to the Blue wire on the bike. Attached the Black wire from the blinker to the Brown wire on the bike.

Install the blinker stalks on the bike with supplied M6x30 screws and washers. Check the function.



vorne/front hinten/rear

