



# TOURATECH

TOURING RALLYE RACING TECHNOLOGY

Mai 2004

01-044-0400-0

01-044-0402-0

## Installation Instructions Hard Part LA R1200GS

### Parts included:

- 1 x Steering Stop
- 2 x Spacer 7,4,27
- 2 x Spacer 7,4,28
- 4 x Dome head screw M4x40
- 4 x Washer M4
- 4 x Nylock nut M4

### Installation:

Set the Hard Part LA Steering Stop on the front part of the telever arm as shown on the first photo.

Use the shorter 27mm spacers in the front bolt attachments and the 28mm spacers in the rear as shown on second photo. Attach with M4x40 screws, nylock nuts M4 and washers M4 under the nylocks.

