



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-044-0430-1

Installation Instructions Folding Shift Lever R1200GS

Contains:

- 1 x Folding shift lever
- 1 x Screw hex M6 x 25
- 1 x Washer



Installation:

Loosen the clamp screw on the BMW shifter and remove it. Now you can pull the shifter off the rod. You may need to use a flat head screwdriver to carefully pry the shifter gap apart.

Remove the countersunk screw off the Touratech shifter and set it on the rod. Determine the correct position with your riding boots.

Tighten the gear lever on the rod with M6x25 screw to max 18Nm.

NOTE: Make sure the sidestand and center stand do not interfere the operation!