



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-044-0432-1

Installation Instructions Adjustable Folding Shift Lever R1200GS

Contents:

- 1 x Gear Lever (two pieces)
- 1 x Screw M6x25
- 2 x Screw domehead M6x16
- 2 x Nylock nut M6
- 1 x Washer



Installation:

Loosen the clamp screw on the BMW shifter and remove it.

Now you can pull the shifter off the rod. You may need to use a flat head screwdriver to carefully pry the shifter gap apart.

Remove the countersunk screw off the Touratech shifter and set it on the rod.

Attach both gear lever parts in wished position with the two domehead M6x16 screws and M6 nuts (inside). Determine the correct length with your riding boots.

Use two holes that are as far apart as possible to attach the two lever parts to ensure maximum strength. Tighten the gear lever on the rod with M6x25 screw to max 18Nm.

NOTE: Make sure the side stand and center stand do not interfere the operation!