



09-044-0470-1

## Installation Instructions Clutch Reservoir Cover R1200GS

### Parts included:

- 1 x Brake reservoir cover Aluminum
- 1 x Retaining clamp Stainless Steel
- 2 x button head screw hex M4x16
- 2 x washer M4
- 2 x nut/nyloc M4
- 1 x Washer M10

### INSTALLATION INSTRUCTIONS:

Remove the left side mirror of your R1200GS.

Place the Touratech reservoir cover support arm behind the cables so that the cables are not damaged or squeezed. Attach the clamp with supplied screws, washers and nuts finger tight. Position the cover correctly close to the reservoir, reinstall the mirror and tighten the screws.

NOTE: With Magura handlebars the cover 044-0470 may need to be bent right to be adapted or you may need to put the extra M10 washer between the mirror hole and the reservoir cover support arm.

