



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

September 2004

09-044-0480-1

Installation Instructions Battery Splash Guard R1200 GS

Contains:

- 1 x Battery Splash Guard
- 4 x Cable Ties 290mm
- 1 x Soft Rubber Strip (approx. 100mm)

Installation:

Remove first the motorcycle seats and disconnect the battery cables (negative cable first and then positive). Remove the battery.

Remove the black round charcoal canister on the left hand side of your bike next to the rear shock.

Push the Alum. Battery Splash Guard up behind the battery compartment (narrow end goes up, lower zip tie tabs forward).

Attach the guard with supplied cable ties to the bike's frame. Supplied soft rubber strip can be attached on the upper frame rail behind battery compartment to reduce rattles and protect the finish.

Reinstall the battery and reconnect the battery cables (positive first then the negative).

Turn on ignition for testing and reinstall the seats.



These instructions are at our current level of knowledge. Legal requirements do not exist. Technical issues subject to change.