



09-044-0490-1

## Installation Instructions Magura AX-line Handlebar BMW R1200 GS

### Contains:

- 1 x Magura AX-line Handlebar
- 2 x Mounting adapter for original hand guards
- 2 x Countersunk screw M12x25
- 5 x Cable ties

## Attention!

Make sure the ignition is off, key removed and your bike is securely on center stand on even and solid ground. Do not operate the brake or clutch levers during the installation.



## Installation:

- 1) Remove the cable ties on the stock handlebar
- 2) Remove the original hand guards
- 3) Carefully disconnect the electrical connectors to brake lever (brake light) and the clutch lever.
- 4) Remove the mirrors as well as brake and clutch levers. Do not let the containers hang down.
- 5) Remove the handlebar controls:

Left: Remove the two screws that are under the lip of the rubber handlebar grip. One is on the top, the other on the bottom

(Photo 1, handlebar is viewed from front towards the rear of the bike).

Right: Remove the switchgear cover and loosen the screw under the cover

(photo 2, handlebar is viewed from front towards the rear of the bike).

- 6) Loosen the clamps that hold the handlebar and take the handlebar off the bike. Carefully push the switch gear off and over the bar ends.

Now install the Magura bar in reverse order. Make sure that the bar is centered, does not interfere with tank or windshield and wires/hoses are properly routed without stretching or scuffing at full right or left turn.

Tighten the clamps to BMW specs. Tighten first the front bolts and then the rear ones

### Additional information:

Some countries/states handlebar change may require official approval or note on vehicle papers.