



09-044-0630-1

## Installation Instructions Brake Light Switch Cover R1200 GS

### Contains:

- 1 x Brake light switch cover R1200GS
- 1 x Screw dome head hex M5x16
- 1 x Washer M5
- 1 x Nylock nut M5

Remove first the original BMW brake light switch cover with #25 torx driver.

Lift the plastic tab at the backside to disengage the plastic cover.

Use the supplied M5 screw instead the BMW torx #25 to attach the Touratech cover as well as the washer M5 and Nylock nut M5 on the backside. Tighten finger tight first, align cover and tighten to BMW torque specs.

Test the brake light function after the installation.

