

Januar 2006

January 2006

Anleitung Rahmenprotektoren BMW R1200 GS / ADV

Instruction: Frame Protectors R1200GS & R1200GS ADV

044-0780



Lieferumfang:

- 1 x Rahmenprotektor rechts
- 1 x Rahmenprotektor links
- 12 x Kabelbinder
- 1 x Streifen Zellgummi

Contains:

- 1 x Frame protector right
- 1 x Frame protector left
- 13 x Cable ties
- 1 x Elastic stripe

044-0785



Achtung: Wichtige Hinweise zur Montage

Es ist empfehlenswert den Rahmen unter dem Protektor mit einem Kratzschutz zu versehen.

Die Rahmenprotektoren werden mit den beiliegenden Kabelbindern am Rahmen befestigt. Achten Sie darauf, dass die Kabelbinder auf der Innenseite / hinten zugezogen werden, so dass Außen / stiefelseitig eine glatte Oberfläche entsteht.

Attention: important tips, explanations

Finish under cable ties can be protected with tape for example.

Cut the elastic stripe into seven pieces and stick in on the inside of the guards.

Put cable ties thru the holes on the frame protector.

Set the frame protector on the frame and pull cable ties tight. Set the cable tie locks on the inside of the frame so that outside surface stays flat and smooth.

Cut extra length on cable tie ends up to the lock.