

Januar 2006

January 2006

PHOTO 1



A

Anleitung Rahmenprotektoren BMW HP2

Lieferumfang:

- 1 x Rahmenprotektor links
- 1 x Rahmenprotektor rechts
- 4 x Kabelbinder 190mm
- 6 x Kabelbinder 130mm

Instruction Frame Protector BMW HP2

Contains:

- 1 x Left frame protector
- 1 x Right frame protector
- 4 x 290mm cable ties
- 6 x 130mm cable ties

PHOTO 2



A

Achtung: Wichtige Hinweise zur Montage

Es ist empfehlenswert zwischen Rahmen und Protektor eventuell einen Kratzschutz anzubringen.

Stecken Sie die Kabelbinder durch die Öffnungen am Rahmenprotektor. Die längeren Kabelbinder werden an den beiden mit "A" markierten Stellen (Foto 1+2) benötigt.

Ziehen Sie die Kabelbinder fest und schneiden die überstehenden Enden ab. Die Kabelbinder sollten auf der Rückseite zugezogen werden, so dass Außen auf der Stiefelseite nichts hervorsteht.

Attention: important tips, explanations

It is advisable to protect frame under the cable ties using tape for example.

Put cable ties thru the holes on the frame protector. Longer cable ties are marked A on photo 1+2.

Make sure frame finish is protected under the cable ties. Set the cable tie locks behind the frame so that the outside stays flat and smooth. Pull cable ties tight and cut cable tie ends.