

01-048-0338-0

DE20070122

Januar 2008

Januar 2008

Anleitung:
Carbonprotektor Lima Deckel

Installation Instruction: Carbon
Fiber Alternator Cover Guard
BMW F800/650(twin)GS

Lieferumfang:

1 x Schutz Kupplungsdeckel Carbon
1 x Tube Silikon
(hochtemperaturbeständig)

Contains:

1 x Alternator cover guard carbon fiber
1 x tube silicone (high temperature
resistant!)



1



Achtung! Wichtige Hinweise

**Kupplungsdeckel vor der Montage
sorgfältig entfetten! Kontrollieren Sie
bitte von Zeit zu Zeit den Sitz des
Carbonteils!**

Attention! Important information!

**Degrease alternator cover carefully
before the assembly! Check adhesion
of the guard in regular intervals.**

Montage:

1. Entfetten / reinigen Sie den Deckel für die Kupplung sorgfältig
2. Bestreichen Sie die Innenseiten des Carbonteils mit dem mitgelieferten Silikon wie in Bild 1
3. Drücken Sie das Carbonteil sorgfältig fest. Achten Sie darauf, dass alle Kanten sauber anliegen! Anschließend den Deckel unter Druck mindestens 12 Stunden fixieren, z. B. mittels Spanngurt (siehe Bild 2)

Installation:

1. Clean and degrease alternator cover carefully
2. Apply silicone at the innerside of the cover guard as shown in pic. 1
3. Press in the guard carefully against alternator cover. Make sure, that all edges fit! The cover guard has to be fixed under pressure or 12 hours (with a strap, for example, as shown in pic. 2)

2

