

Januar 2008

Januar 2008

DE20070122

**Anleitung:**  
Carbonprotector Kupplung Deckel

**Installation Instruction:**  
Carbon Fiber Clutch Cover Guard  
BMW F800/650(twin)GS

**Lieferumfang:**

1 x Schutz Kupplungsdeckel Carbon  
1 x Tube Silikon  
(hochtemperaturbeständig)

**Contains:**

1 x Clutch cover guard carbon fiber  
1 x tube silicone (high temperature  
resistant!)



**Achtung! Wichtige Hinweise**

**Kupplungsdeckel vor der Montage  
sorgfältig entfetten! Kontrollieren Sie  
bitte von Zeit zu Zeit den Sitz des  
Carbonteils!**

**Attention! Important information!**

**Degrease clutch cover carefully  
before the assembly! Check adhesion  
of the guard in regular intervals.**

**1**


**Montage:**

1. Entfetten / reinigen Sie den Deckel für die Kupplung sorgfältig
2. Bestreichen Sie die Innenseiten des Carbonteils mit dem mitgelieferten Silikon wie in Bild 1
3. Drücken Sie das Carbonteil sorgfältig fest. Achten Sie darauf, dass alle Kanten sauber anliegen! Anschließend den Deckel unter Druck mindestens 12 Stunden fixieren, z. B. mittels Spanngurt (siehe Bild 2)

**Installation:**

1. Clean and degrease clutch cover carefully
2. Apply silicone at the innerside of the cover guard as shown in pic. 1
3. Press in the guard carefully against clutch cover. Make sure, that all edges fit! The cover guard has to be fixed under pressure or 12 hours (with a strap, for example, as shown in pic. 2)

**2**
