

01-049-0105-0

Dezember 2006

January 2007



**Anleitung Gepäckbrücke Alu  
BMW G650X**

**Instruction: Alu Luggage Rack  
BMW G650X**

**Lieferumfang:**

**Contains:**

- 1 x Gepäckbrücke Alu klein
- 4 x Distanz Alu 18mm
- 4 x Zylinderkopfschraube M6x35
- 4 x U-Scheibe M6 groß

- 1 x Luggage rack Alu Small
- 4 x Spacers 18mm Aluminium
- 4 x Allen head screws M6x35mm
- 4 x Washers M6 large

**Achtung! Wichtige Hinweise**

**Attention: important tips, explanations**

**Maximale Last 5kg!  
Schraubensicherung mittelfest  
verwenden! Nicht für X-Country! Achten  
Sie bitte beim Entfernen und beim  
Anbau der Sitzbank darauf, dass die  
hintere Kante der Sitzbank nicht an der  
Gepäckbrücke scheuert!**

**Maximum Load 5kg (11 lbs)! Use  
thread locking compound! Doesn't fit  
with X-Country!  
Take care upon removing the seat that  
seat does not scrub on the edge of the  
luggage rack.**

1



**Montage**

**Assembly**

1. Entfernen Sie zuerst den Endtopf der Auspuffanlage! Dies erleichtert die Montage der Gepäckbrücke! (Bild 1)
2. Entfernen Sie nun die Alu-Kappen am Heck wie in Bild 1 (beidseitig)
3. Platzieren Sie die Gepäckbrücke wie in Bild 2 und befestigen Sie diese mit

1. Remove the muffler for easier access to mounting screws (photo 1)
2. Remove the caps from the threaded holes (photo 1) (two on each side.)
3. Place the luggage rack on the tail as in photo 2 and attach it with:

2



- 4 x U-Scheibe M6 groß
- 4 x Zylinderkopfschraube M6x35
- 4 x Distanz Alu

- 4 x washers M6 large
- 4 x Allen screws M6x35
- 4 x Spacers Alu

**Achtung! Schraubensicherung mittelfest verwenden! Vor dem Festziehen der Schrauben die Gepäckbrücke unbedingt ausrichten!**

**Note! Use thread locking compound on all screws. Align luggage rack before tightening screws!**