



# TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-051-0521-1

## Installation Instructions Engine and Fairing Crash Bars V-Strom DL1000

### Contains:

- 1 x Crash bar left
- 1 x Crash bar right
- 1 x Connecting bar
- 1 x Mounting material



### Installation:

Loosen the screws as shown on photos 1 + 2 of the motor/frame attachment as well as side covers on both sides of the radiator.

Put the connecting bar over the radiator, flat spots parallel to ground, and attach it to the radiator thru the side covers. Do not tighten the bolts yet.



Put two spacers in the frame holes supplied in the mounting hardware. There are two different spacers so make sure to use correct ones in each frame attachment. Set the crash bars on the bike and attach the upper mounting point with the M8x45 bolts and washers. For the lower left attachment, use the M10x100 bolt and lower right the M10x80 and spacers.

Do not tighten the bolts yet.

Attach the connecting bar to the crashbars with the M6x20, washers and nylock nuts.

Now tighten all bolts.

