



# TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-051-1205-1

## Installation Instructions Chain Guide Off Road F650 GS/Dakar

### Contains:

- 1 x Hard plastic off road chain guide
- 1 x Bracket
- 1 x Spacer
- 2 x Screw hex M6x40
- 1 x Screw hex M6x45
- 1 x Screw hex M6x16
- 2 x Nylock nut M6
- 6 x Washer M6



Photo: 1



Photo: 2



Photo: 3



Photo 4

## Installation:

Remove the original chain guide. It will no longer be used. Do not tighten screws until all points are loosely attached.

Install first the black plastic chain guide. Bend it open in the middle and slide the chain in (photo 2).

Insert the spacers in the chain guide using channel pliers until they lock in the plastic chain guide (photo 3).

Set the bracket over the swing arm and attach on the original attachment point of the chain guide with screw M6x45, washer M6 and spacer.

Now the chain guide is pushed from below to the bracket and attached with two screws M6x40, washers M6 and nylock nuts M6 (photo 4).

Tighten all screws, check for correct chain tension and lubrication.

Optional Touratech chain guard is attached on the bracket lower position with screw M6x16.