



09-053-0058-1

Installation Instructions Top Case Bracket R1200 GS

Page 1

Contents:

- 1 x Base
- 1 x Top Case Bracket (premounted)
- 1 x mounting material
 - 2 x Hex screw M6x40
 - 1 x Hex screw M6x20
 - 5 x Countersunk screw M6x12
 - 4 x Countersunk screw M5x16
 - 5 x Cap nut M6
 - 4 x Nylock nut M5
 - 8 x Washer large M6
 - 4 x Washer large M4
 - 2 x Spacer



Top Case L (050-0040) pictured

NOTE:

Top Case Bracket is not intended to be used with Top Case XL 050-0041!

Preparation:

Remove the original rear rack of your R1200GS. It is attached with three screws to the rear. More info can be found in owner's manual.

Installation:

1) The base will be attached in the same points as the original with supplied spacers. Remove the original BMW spacers on the sides and use the supplied spacers with Hex screws M6x40 and large washers M6. Use the M6x20 Hex screw with large washer M6 for the third attachment point.

Note: Leave screws finger tight first and refer to the owner's manual for BMW torque specs.



2) The lower plate of the Top Case Bracket is attached with four countersunk screws M5x16 on the base (left photo).

The middle plate can be reattached then preferably using some locktite on the bolts (right photo).



3) Center the top plate will be attached on the bottom of the Top Case. Align the plate so that the Top Case has ample room for the passenger grip. Mark the 5 holes and drill to a diameter of 6.5 mm. The X-shaped reinforcement piece has 5 holes corresponding to holes in the plate that fastens to the bottom INSIDE the Zega case

Fasten with the 5 short machine M6x12screws countersunk on the bottom of the plate, the 5 large washers M6 and 5 dome nuts on the inside of the Zega Case. Use locktite or similar thread locking compound. Silicon can be also used to properly seal the holes.



09-053-0058-1

Installation Instructions Top Case Bracket R1200 GS

Page 2

To attach the Zega case to the rack, slide the 2 rectangular latches at the front of the case into the guides and pull the latch towards you.

The box should fall flush with the rack and the latch plate should retract toward the front of the case.

It may take a coaxing for this to happen until the latch loosens up a little. Turn the key to the right to lock.

The lock must ALWAYS BE LOCKED when driving.

To remove the Zega case from the rack, see the first step above.

Consider the weight of the Zega case and contents when loading your motorcycle.

Do not exceed the maximum load limits for the make and model of your motorcycle.

DO NOT exceed 130km/h or about 78 MPH with the Zega case installed.

The weight and height of the load changes the center of gravity of your motorcycle and therefore affects the riding dynamics and handling.

Use these instructions at your own risk. These instructions are new and have not been tested by independent installers. Touratech and Touratech-USA assume no responsibility for errors using these suggestions. If you have any doubts about your ability to install the top box, please contact a professional mechanic.