



TOURATECH

TOURING RALLYE RACING TECHNOLOGY

01-055-0085-0 01-055-2185-0
to to
01-055-0089-0 01-055-2189-0

Installation Instruction Sport Seat R11xxGS all heights

Contains:

1 x Sport seat
4 x Screw hex M6x25
4 x Screw hex M6x16
4 x Spacer
4 x Washer large M6



Installation:

Remove the wire bracket assembly that is installed on the bottom of the original rider seat. Remove the four rubber mounts including washers. Wire bracket assembly is then installed on the new sport seat by using the threaded holes and screws M6x16 and washers M6.

Supplied four spacers may be needed depending on the bike. The spacers can be used between the wire bracket assembly and the seat, in case of tolerances (tolerances can be on both seats and/or motorcycles). If spacers are used, please use the supplied longer M6x25 screws.

Foam strip on original metal tank may no longer be necessary with Touratech seat and can be shortened or removed.

Make sure the rear hooks engage properly in the rear slots when seat is installed on the bike. Be careful not to scratch the rear frame finish with the hooks when putting seat on or removing it.

The seat can be set on the bike on the lower seat position. Press the seat down front and back at the same until it engages.



When necessary, please install the spacers at these positions between frame and seat pan.

Attention!

Tighten the M6 screws to max. 12Nm torque!

These instructions are at our current level of knowledge. Technical issues/details subject to change. Legal requirements do not exist.