

Oktober 2008

October 2008

DE20080314



Anleitung: Lenkerhalterung Garmin Oregon 400 Fahrrad / Motorrad

Lieferumfang 065-0008:

1 x Lenkerhalter Motorrad (nicht abschließbar)
4 x Elastikpuffer Ersatz

Lieferumfang 065-0009:

1 x Lenkerhalter Fahrrad
4 x Kantenschutzprofil
4 x Elastikpuffer Ersatz

Lieferumfang 065-0010:

1 x Lenkerhalter Motorrad abschließbar
4 x Elastikpuffer Ersatz

Achtung! Wichtige Hinweise

Alle Schraubverbindungen nach 50Km kontrollieren und nachziehen! Achten Sie unbedingt vor Fahrtbeginn darauf, dass die Verriegelung sicher eingerastet hat!

Montage auf Lenkermittelstrebe:

1. Entfernen Sie die Muttern und U-Scheiben an der Halteschelle und nehmen Sie diese ab (Bild1)
2. Halterung wie in Bild2 auf der Strebe platzieren und mit der Schelle wieder befestigen! Darauf achten, dass die Schrauben mit dem Vierkantbund korrekt in den Aussparungen der Halteplatte sitzen! Abbildung zeigt beispielhafte Befestigung mit ähnlichem Gerät!

Montage mit RAM-Mount-Adapter:

1. Halteschelle und Muttern entfernen, Schrauben wie in Bild3-1 platzieren und Adapter mit den vorhandenen U-Scheiben und Muttern verschrauben!
2. Halterung wie in Bild3-2 auf dem Kugel-Gelenk-Adapter befestigen! Abbildung zeigt beispielhafte Befestigung mit ähnlichem Gerät!

Montage Fahrradhalterung:

1. Klemme wie in Bild 3-3 öffnen und 4 x Kantenschutz montieren, evtl. mit Sekundenkleber fixieren!
2. Halterung wie in Bild 3-4 am Lenker Befestigen!

Installation Instruction: Handlebar Mount Garmin Oregon 400 Bike/MC

Contents 065-0008:

1 x Handlebar mount MC (non-lockable)
4 x Rubber isolator spare

Contents 065-0009:

1 x Handlebar mount bicycle
4 x Edge protection plastic
4 x Rubber isolator spare

Contents 065-0010:

1 x Handlebar Mount Motorcycle Lockable
4 x Rubber isolator spare

Attention: important tips, explanations

Check all screws after 50Km and retighten if necessary! Make sure GPS mount is securely attached on the vehicle and the GPS unit is securely in the mount before each ride!

Assembly on Handlebar Crossbar:

1. Remove the nuts and washers of the C-clamp on the bottom of the mount; then remove the C-clamp (Photo 1).
2. Set the mount on 12mm (1/2inch) crossbar as shown on photo and secure with the C-clamp, washers and nylock nuts. Make sure the carriage bolt square head collars fall correctly in the square holes on the GPS mount plate. Photo is showing an example of similar unit.

Assembly with RAM-mount adapter:

1. Remove the nuts, washers and the C-clamp on the bottom of the mount as shown in photo 1. Install the RAM ball mount adapter with original screws, washers and nuts as shown in photo 3-1.
2. Attach then the RAM ball mount adapter with RAM socket arm as shown in photo 3-2. Photo shows an example of similar unit.

Assembly on Bicycle Handlebar:

1. Open the clamp as shown in photo 3-3 and set the four clear protective plastic strips on the clamp (can be secured with Loctite).
2. Set the mount on the handlebar as shown in photo 3-4.

Oktober 2008

October 2008

DE20080314


Einlegen des Gerätes:

1. Schloss entriegeln (bei Motorrad abschließbar)
2. Halterung mittels Verriegelungshebel ganz öffnen. Diesen dazu bis Anschlag nach oben ziehen (Bild4)

Operation of GPS Cradle:

1. On lockable motorcycle mount, unlock the key lock.
2. Open the cradle completely with the latch completely as shown in photo 4.



3. Gerät wie in Bild5/6 einlegen. Achten Sie darauf, dass das Gerät überall exakt anliegt. Achtung! Zum besseren Verständnis ist die Halterung mit geschlossenem Deckel dargestellt!

3. Slide the GPS unit in the cradle as shown in photos 5 + 6. Make sure GPS unit is properly aligned all around. Note: for better demonstration the photo shows unit inside the cradle with closed top.

4. Verriegelungshebel bis zum hörbaren Einrasten nach unten drücken (Bild7).

4. Press the closing latch properly down until it positively snaps closed (photo 7).

5. Schloss verriegeln und Schlüssel abziehen!(bei Motorrad abschließbar)

5. Turn the lock closed on lockable motorcycle mount and remove the key.

