

065-0056 Garmin StreetPilot III Locking Mount

(Please refer to photos on German instruction sheet)

Contains:

- 1 x Locking mount StreetPilot III (preassembled)
- 1 x Screw domehead M3 x 6
- 1 x Washer Large M3

Preparation of Garmin StreetPilot III:

Garmin universal bracket has to be removed. Unscrew the small thumbscrew and unlatch the bracket. Two attachment screws can now be removed and the bracket taken off.

Installation:

Touratech 065-0056 Garmin StreetPilot III mount can be now attached on any 12mm or ½ inch tubular bar such as handlebar crossbar. If handlebar does not have a crossbar, adapters are available for many motorcycle models.

Set the GPS unit in the mount by first engaging the lower or front hooks in the recesses on the GPS housing as shown on first photo. Then push the GPS back in the mount and engage the lock as shown on second photo. Tight engagement is required.

12V power cable plug can be inserted in the socket. Study the plug and socket carefully – it can only be inserted in one way.

If needed Antenna bracket can also be moved in different position by removing the two fasteners, rotating the bracket and reattaching the fasteners.

Supplied screw and washer are used for added security in offroad use. Screw can be inserted through the back of the mount into the thread in GPS housing.

Rubber cap can be attached on the handlebar and used to protect power cable when GPS is not used.

ATTENTION:

Locking mount is theft deterrent but it is not a 100% guarantee against theft! It is always recommended to remove the GPS when leaving your vehicle. Touratech GPS mounts are developed for motorcycle use and assembled with great care but there is no guarantee a fine electronic device such as GPS won't suffer vibration related damage.