

09-300-0145-1

## Installation Instructions Fork Protectors F650 GS

### Contains:

- 1 x Set of front fork protectors
- 2 x Clamp part
- 2 x Slider part
- 1 x Allen screw M8x70
- 1 x Allen screw M8x60
- 1 x Allen screw M8x50
- 1 x Allen screw M8x40
- 1 x Nylock nut M4
- 4 x Allen screw M4x12
- 4 x Washer M4
- 4 x Spacer (for F650GS Dakar TT low fender)
- 2 x strip of clear protector tape



### Installation:

Removing of front wheel or front forks is not necessary for installation.

1) Remove the fork brace between the front forks. The left rear screw is attached with a nut from below. Slider parts are attached under the fork brace with original screws. For left rear use the M8x60 for F650GS, M8x70 for F650Dakar or M8x40/M8x50 for models with older fork brace.

2) Clean the area directly under the lower triple clamp (2nd photo) and put the clear protector tape around the forks.

3) Put the fork protectors through the lower slider parts and attach on the top with the clamp parts, M4x12 screw and M4 washers (2nd photo)

**Attention: Careful not to over tighten the top clamp part screws and pull the threads out of the plastic! Small gap will stay between the clamp part and the fork protector**

Tighten the fork brace screws according to BMW specs.

Note: Low fender needs to be cut so that the fork protectors can move free (3rd photo)  
Please use the supplied spacers instead of the stock 25mm spacers on F650GS Dakar.