

09-300-0147-1

Installation Instructions Rear Shock Protection BMW F650 GS

Contains:

- 1 x Black Plastic Rear Shock Protector
- 1 x Rear Shock Protector Bracket
- 4 x Countersunk screw M4x12 (Phillips)
- 4 x Nylock nut M4
- 1 x Nylock nut M12
- 4 x Washer M4



Preparation:

Attach the rear shock protector bracket with the four countersunk screws M4x12, nylock nuts M4 and M4 washers on the rear shock protector as shown on top photos.

Installation:

Suspend the motorcycle so that the rear shock is extended and the swing arm is unloaded. Make sure your bike is secure and fix the swing arm with some tie downs or rope in a position where the rear shock linkage can easily be loosened and reinstalled.

Loosen the bolt on the bottom linkage point (make sure not to loose/damage to the bearing dust covers) so that you can then loosen the lower rear shock attachment bolt.

Slide the rear shock protector over the rear shock as shown on lower right photo and attach it with the rear shock to the lower shock attachment point.



Reattach the bottom linkage point with the supplied M12 nylock nut to BMW torque specs. Do not forget to check that the bearing dust covers are properly in place.

