

09-370-0170-1

Contains: 1 x Lift handle 2 x Screw counter sunk M8x30 4 x Washer M8

Installation Instructions Lift Handle KTM LC8





Installation:

Remove the passenger foot peg mount on the left side.

It will be reattached with the lift handle as shown on the photo with M8x30 screws. The lift handle is installed under the rear foot peg mount.

Install four washers between the grip and the motorcycle frame. The grip can otherwise interfere with the rear shock

These instructions are at our current level of knowledge. Legal requirements do not exist. Technical issues subject to change.