

**Anleitung: Carbonprotektor  
Kupplungsdeckel  
Husqvarna 310/450/510 TE ab 2009**

**Instruction: Carbon protector  
clutch cover  
Husqvarna 310/450/510 TE from 2009 -**

Lieferumfang:

1 x Protektor  
1 x Silikon hitzefest

Contents:

1 x Protector  
1 x silicone heat resistant

**Achtung! Wichtige Hinweise**

**Alle Schraubverbindungen nach 50Km kontrollieren und nachziehen!**

**Bei zusätzlicher Verwendung von Original-Zubehör oder Zubehör anderer Hersteller auf Freigang, Passform und auf mögliche Kollisionen prüfen!**

**Alle Oberflächen vor der Montage entfetten!**

**Den Protektor mindestens 12 Stunden fixieren wie in Bild2, damit der Kleber aushärten kann!**

**Der Protektor muss sehr sorgfältig und exakt positioniert werden!**

**Bremshebel oder Schalthebel müssen für die Montage möglicherweise abgebaut werden!**

**Attention: important tips, explanations**

**Check all screws after 50Km and retighten if necessary!**

**When fitting with additional accessories, original or third-party, ensure a precise fit and check for possible interference!**

**Degrease all surfaces before assembling!**

**Protector must be fixed in place for 12 hours as illustrated in picture 2! Adhesive needs 12 hours to cure!**

**Make sure that the position of the protector is absolutely accurate before allowing the silicone to cure!**

**If necessary remove the brake- or gear lever to improve access!**

