

September 2009

September 2009

DE20080314



Anleitung:
Carbonprotector Kupplungsdeckel
BMW F800R/S

Lieferumfang:

- 1 x Carbonprotector Kupplungsdeckel
- 1 x Tube Silikon hitzefest

Installation Instruction:
Carbon Fiber Clutch Cover Guard
BMW F800R/S

Contains:

- 1 x Clutch cover guard carbon fiber
- 1 x tube silicone (high temperature resistant!)



Achtung! Wichtige Hinweise

Alle Schraubverbindungen nach 50Km kontrollieren und nachziehen!
Den Sitz des Carbonteils von Zeit zu Zeit kontrollieren!
Alle Klebeflächen vor der Montage sorgfältig reinigen und entfetten!

Attention: important tips, explanations

Check all screws after 50Km and retighten if necessary!
Check adhesion of the guard in regular intervals.
Degrease clutch cover carefully before the assembly!

Montage:

1. Entfetten / reinigen Sie alle Teile sorgfältig
2. Bestreichen Sie die Innenseiten des Carbonprotectors mit dem mitgelieferten Silikon wie in Bild1 gezeigt.



Installation:

1. Clean and degrease all parts carefully
2. Apply silicone at the inner side of the Cover guard as shown in pic. 1



3. Drücken Sie den Carbonprotector sorgfältig fest. Achten Sie darauf, dass alle Kanten sauber anliegen! Anschließend den Deckel unter Druck mindestens 12 Stunden fixieren, z. B. mittels Spanngurt (siehe Bild2)
3. Press in the guard carefully against clutch cover. Make sure, that all edges fit! The cover guard has to be fixed under pressure or 12 hours (with a strap, for example, as shown in pic. 2)