

For DC Use Only

These are general instructions. Some machines may require you to remove the bulb base and some may not. **Remove base with a gentle counter clockwise twist.**

• Install base in headlight bucket, using factory clips.

• Tuck the wire connector and pod in the area between the headlight reflector and the outside shell. Some bikes will have a rubber boot, in this case the boot usually will go between the bulb base & fan housing. In this case the driver pod & connector will be on the outside of the housing.

• Install the bulb, by inserting it into the base and turning it clockwise. The emitters should be facing left & right. (Not up & down)

Check the headlight aim. Often it is necessary to re-adjust your headlight after bulb install.

NOTE: The Base of your new Cyclops LED headlight replacement bulb has a removable base to aid in installation. *Please see below photos*.

Base Removal Instructions

Shown Using H4 3800





<u>Step One</u>: Remove bulb from packaging. Lay on a clean surface.



<u>Step Three</u>: Gradually slide the base towards you.

<u>Step Two</u>: Hold the fan with one hand, having the blub face you. Notice the notch (<u>red arrow</u>). Twist the base with your other hand to release.



<u>Step Four</u>: Success you have removed the base from the bulb.

*** **NOTE**: If your vehicle uses a rubber boot between the bulb and connector, that should be able to be reused. Sometimes a slight modification is necessary.