

01-040-7301/-7302/-7304/-7305-0

DE20080314

Mai 2008

May 2008



**Anleitung: Spoiler für Handprotector GD**

Lieferumfang:  
1x Satz Spoiler (LI+RE)  
4x LiKo M5x14  
4x SeSi M5  
8x U-Scheibe M5

**Achtung! Wichtige Hinweise**

**Alle Schraubverbindungen nach 50Km kontrollieren und nachziehen!**

**Installation Instruction: Spoilers for Hand Protectors GD**

Contents:  
1 x Spoilers set (L+R)  
4 x Screw dome head M5x14  
4 x Nylock nut M5  
8 x Washer M5

**Attention: important tips, explanations**

**Check all screws after 50Kms / 30miles!**



**Montage**

Falls die TT Handprotectoren GD schon montiert sind, sollten Sie sie zur Spoilermontage demontieren, da sie im angebauten Zustand etwas unter Spannung stehen könnten. Nehmen Sie den Spoiler und legen Sie ihn an den Protektor an, A+B. Bohren Sie die Löcher mit einem Akkuschauber oder einer Bohrmaschine mit einem Bohrer Durchmesser 5,1 ab, C1+C2. Dabei darauf achten, das sich der Spoiler während des bohrens nicht verschiebt. Wenn Sie die Löcher drin haben, schrauben Sie den Spoiler an. Nehmen Sie dafür die beigelegten Schrauben, Muttern und U-Scheiben, D. Ziehen Sie die Schrauben an und montieren Sie den Protektor wieder an Ihr Fahrzeug. Beachten Sie dabei die Montageanleitung für den Protektor.

**Assembly**

Remove the hand protectors GD if they are already installed. Set the spoiler on the inside of the the hand protector as shown in photos A + B. Drill holes onthe hand protector using the spoiler as template (C1 + C2). Make sure the spoiler does not move during drilling of the two holes. Istall spoilers to the hand protectors using supplied hardware as shown in photo D with nut and washer on the inside, dome head scew and washer on the outside. Reinstall the hand protector on the handlebar.