

http://www.touratech-usa.com/instl/instl_040-1350.html

back to:
www.touratech-usa

email the [webmaster](#)



(similar to R1150 GS shown)

TOURATECH Windscreen spoiler.

part# 040-1350

**for GS-
ADVENTURE**

Synopsis

The Windscreen spoiler is easy to remove for off-road riding. It is then easily replaced for highway comfort.

- 1) Place the spoiler on the top edge of the windscreen.
- 2) Push upward on the silver cowling then engage the metal hook between the silver cowling and the upper edge of the black speedometer housing.
- 3) Tighten the webbing to hold the spoiler in place.

Use these suggestions at your own risk.

- These instructions are new and have not been tested by independent installers.
- The instructions may not be complete.
- Touratech and Touratech-USA assume no responsibility for errors using these suggestions.

If you have any doubts about your ability to install the spoiler, please contact a professional installer.



Spoiler placed at top of windscreen. Webbing is behind windscreen and the steel clip



engages the speedometer housing on the R1150GS Adventure.

These screws are used to adjust the angle of the windscreen.



Flex the plastic silver cowling upward to open space behind the cowling. Then drop the stainless steel clip into the cavity behind the black speedometer housing. Release the silver cowling (to capture the clip). Then tighten the strap to secure the spoiler onto the windscreen.

http://www.touratech-usa.com/instl/instl_040-1350.html