


09-041-0632-1

Installation Instructions Adjustable Shifter R1150 GS



Removal of stock shifter:



1A: Unscrew the attachment for the shock preload adjustment knob.

1B: Remove the small half round security pin and loosen the ball joint.

1C: Unscrew the three screws holding the foot peg support.

1D: Loosen the screw holding the original shifter from behind. This screw can be tight and may require some heat to loosen.

Installation:

Install the new adjustable shifter in reverse order. Make sure to torque screws according to manufactureres instructions or check the tightness after some use.



Adjustment:

Adjust the shifter to suitable length. Length of shift throw can be later adjusted by the shift linkage. Fig. 2A.

Sehen Sie auch in unserem Katalog oder im Internet unter www.touratech.de

Diese Anleitung ist nach unserem derzeitigen Kenntnisstand verfasst. Rechtliche Ansprüche auf Richtigkeit bestehen nicht. Technische Änderungen vorbehalten.