



# TOURATECH

TOURING RALLYE RACING TECHNOLOGY

01-055-2110-0

Installation Instruction  
Seat Extension R1150GS ADV

## Contains:

- 1 x Seat Extension R1150GS Adventure
- 1 x Passenger hand grip
- 2 x Screw dome head M6 x 70
- 4 x Screw counter sunk M6 x 25
- 4 x Washer M6
- 4 x Spacer black plastic 12,6,5

## Installation:

Remove the original passenger grip. Loosen the four M6 screws on the underside of the rear frame (Photo 1).



Set the supplied plastic spacers in the holes left free by original grip attachment. (Photo 2)

Set now the seat extension on the rear rack and attach it with supplied M6x25 screws and washers from underneath using same attachment points as the passenger grip. Extension needs to be pushed slightly forward against the seat. (Photo 3)



Loosen now the rear screws on the rear rack. (Photo 3)  
Attach then the new grip on these attachment points using the dome head M6x70 screws. (Photo 4)  
Make sure the grip is slightly leaning backwards.

